



UNDER HEADER Jamb Preparation:

The Under Header Door requires a smooth, flat, and uniform door jamb with at least 8" of width (wall thickness). All of the door hardware with the exception of the valence panel will mount directly to the side jambs.